

Flange installation

## CF862

All directions





Ontology	main bead	Auxiliary beads	retainer
aluminum	SUJ2	SUJ2	Steel



A : Standard type




B : Chip removal type



Garbage discharge hole

How to order



Choose a type  
 Standard type..... **A**  
 Chip removal type..... **B**

Can be used in all directions, up and down, left and right

unit : mm								
D	D1	L1	H	t	P.C.D	a	d	Load capacity N
56	30	5	21	6	44	6.5	19.05	500
66	42	6.5	29.5		54		25.4	1400